

Aqua Box1, Box2 and Box3 Lens Installation Guide

National Products, Inc.

Instructions

Wash your hands prior to installing the lens. This will insure that no oils are passed onto the lens or that debris does not interfere with proper seal. Push the lens from inside the cover toward the outside. While keeping pressure on the lens inside the frame, gently role the lens over the outer lip of the cover. Once the lens has fully engaged the raised lip of the Aqua Box cover, inspect seal for proper seat. Now, look at the inside of the cover and complete the installation by seating the lens inside the provided groove. Lens should seat snugly with no visible air pockets or wrinkles once in place.

Three foam pads are included with the kit. Stack or choose a single pad to best accommodate your device. Should you need to route power or data cables into the box, punch out the center plug at the bottom of the box. This area is stamped for your reference.

No lock is supplied with this holder although it is designed to allow for the use of one. Four screws and four nuts facilitate the attachment of a RAM ball base with the AMPS hole pattern. Specifically, the RAM-B-202 or RAM-202.

